

Another Innovative



Hydro Seeding Product

Mixing Instructions

Loading Instructions

1. Start the flow of water into the tank.
2. Pre-wet hoses and prime pump by running water through the mulch lines.
3. Engage the agitator at $\frac{1}{2}$ speed.
4. If adding seed and/or fertilizer add when the water level reaches $\frac{1}{4}$ full.
5. Load all of the HydroStraw before tank reaches $\frac{3}{4}$ full. Do not hesitate to shut off water before this step is completed.
6. Resume filling the tank with water until the tank is full.
7. Set the engine to full throttle for approximately $\frac{1}{2}$ minute. Then set the engine throttle to about $\frac{1}{2}$ speed to begin hose application operations.